

# KBH NEW STYLE SEED TENDER WIRELESS REMOTE PAIRING INSTRUCTIONS

## *1. To pair the remote to the receiver:*

- a. Make sure the remote is on (the switch is on the back of the remote – I = on & O = off)*
- b. Now **PRESS** the #2 button on the remote and **RELEASE IT.***
- c. Next, hold the receiver switch in the **REMOTE** position for 2 seconds (found on driver's side rear of the trailer above the engine)*
- d. Now **PRESS** the #1 button on the remote and the belt should run.*
- e. Next, **PRESS** the #1 button on the remote again to stop the belt.*
- f. Now your remote is paired.*
- g. If none of the buttons have been pressed on the remote for 30 minutes, then the remote will automatically turn off.*